

Replace the Pt100

Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know

- **Explanation**

If the Pt100 is bad or one of the leads is broken, the Pt100 needs to be replaced.

Parts:

PT100 SENSOR, TOP PSC 1030 JAKE Part: [60066565](#)

Check all the connections in the circuit

Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know

- **Explanation**

Perform a pull test on each of the wire connections to see if a wire is loose. Perform a continuity check on the circuit. Repair any opens found. If the open is in the Pt100 lead, then replace the Pt100.

AN12 junction box drawing Doc: [/D6015816](#)