

Replace the defective PT100 sensor

Does this solve the problem?

1] Yes

2] No

3] I don't know

- [Explanation](#)

IN THE +AN14 CABINET:

Check PT100 connections and tightness in the +AN14 panel.

Check the input in TOI U01 terminals 403 and 405

Use a multimeter set to read Ω and measure the resistance across the leads of the PT100.


Use the resistance/temperature conversion chart to determine the actual measured value.


Relevant documentation	
Description	DMS No.
PT100 Resistance/Temperature chart	0039-6203

If the value matches that taken from the TAC Temperature menu, then the circuit is working as designed.

If the value is unreal (-40 to 200 °C), then the PT100 is faulty and must be replaced.

Relevant spare parts	
Description	Item No.
PT100 180-4-7M Ø6x60mm	60009281







881 - PT100 fault water after cooler - V82



Replace the defective varistor

Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know


- [Explanation](#)

IN THE +AN1 CABINET:

Check the Varistors incoming /outgoing PIN terminals for any loose connections.



Varistors (F43 (MKIII+) / F11 (MKII-)) can be tested individually by placing a multimeter (set to measure Ω) lead on the common (earth) side of the varistors and the other on the individual varistor terminals. The resistance value over the varistor should be ∞ or in the high M Ω range. If the resistance is lower, the varistor has been damaged by an over voltage in the circuit and must be replaced.





Relevant spare parts	
Description	Item No.
VARISTOR BOX X8	51706201

Varistor box F43/F11:

Press clip on top and bottom of varistor box and remove varistor assembly from housing:



Replace the defective TOI

Does this solve the problem?

- 1) Yes
- 2) No
- 3) I don't know

- [Explanation](#)

IN THE +AN1 CABINET:

If the value does not match that taken from the TAC Temperature menu, then the cause is likely a faulty Nacelle TOI (check other panel temperature alarms, as these will likely be affected as well).

Relevant spare parts

Description	Item No.
-------------	----------



Check the temperature value in the TAC menu.

